


TEMPERATURE MEASUREMENT

IN AIR AND GASES

outdoor temperature sensor



■ The outdoor temperature sensor is placed on the side window pane and is fixed by closing the window. Due to the plastic construction a damage of the window pane and the gasket is avoided. A version with two magnetic feet can be mounted at any place on the steel vehicle body.

Connection ends:

- miniature thermoplug
- standard plug
- free ends _____ mm
- other connection ends
- miniature socket
- standard socket

Connection cable:

- Thermocouple extension cable
2 x 0,22 mm² (FEP / C / FEP)
- Thermocouple extension cable
2 x 0,22 mm² (FEP / FEP)
- other connection cables (see page 39)

Connection cable length:

- 0,50 m
- 1,00 m
- 1,50 m
- 2,00 m
- 3,00 m
- 5,00 m
- 10,0 m
- other length _____ m

outdoor temperature sensor with magnetic feet

CONFIGURATION EXAMPLE

item no.	thermocouple	cable	cable length mm	connection ends	dimension mm
T999-054-584	type K	2 x 0,22 mm ² FEP/C/FEP	2500	miniature thermoplug	Ø 25 x 100

outdoor temperature sensor for the window pane

CONFIGURATION EXAMPLE

item no.	thermocouple	cable	cable length mm	connection ends
T999-053-055	type K	2 x 0,22 mm ² FEP/FEP	2000	miniature thermoplug